

SELECTION GUIDE - ARCHITECTURAL



SUBSTRATE	Fibrous cement board	Exterior panel	PLYWOOD PANEL	MDF PANEL	PARTICLE BOARD	ACOUSTIC PANEL	HONEYCOMB PANEL
TIMBER BATTENS OR FRAMES	N/A	N/A	PC-F1A / RF1 / AF1 + M1B / M2H / SM2H / VM1 VL-F3 / F3H + M3 / M3H SL-SFA + M18 MC-F5 / F10 + M5 LP-F8 / AF8A + M8A / SM8AS / SMX	PC-F1A / RF1 / AF1 + M1B / M2H / SM2H / VMX VL-F3 / F3H + M3 / M3H SL-SFA + M18 MC-F5 / F10 + M5 LP-F8 / AF8A + M8A / SM8AS / SMX	PC-F1A / AF1 + VM1 / M2H VL-F3 / F3H + M3 / M3H LP-F8 / AF8A + SM8AS / SMX	PC-F1A / RF1 / AF1 / SF1 + SM1AC	PC-F1A / RF1 / SF1 / AF1 + SM2 / SM2H LP-F8 + SM8AS MC-F5 / F10 + M5 LP-F8 / AF8A + SM8AS / SMX
STEEL FRAMES e.g. Rondo	N/A	N/A	PC-SF1 + M1B / M2H / SM2 / SM2H VL-F3 / F3H + M3 / M3H MC-F5 / F10+ M5	PC-SF1 + M1B / SM2H / VMX VL-F3 / F3H / F3FR + M3 / M3H / M3FR MC-F5 / F10 + M5	PC-SF1 + M1B / SM2H (+ glue thread)	PC-SF1 + SM1AC	PC-SF1 + SM2 VL-F3 / F3H / F3FR + M3 / M3H / M3FR MC-F5 / F10 + M5
STEEL FRAMES (See page 64)	N/A	N/A	SL-FB + M18 - screw fix	SL-FB + M18 - screw fix	SL-FB + M18 - screw and adhesive fix	N/A	SL-FB + M18 - screw and adhesive fix
ALUMINIUM (See Page 63)	N/A	N/A	SL-FA + M18 with screw fix For rails without channels use SL-SFA	SL-FA + M18 with screw fix For rails without channels use SL-SFA	SL-FA + M18 with screw and adhesive fix For rails without channels use SL-SFA	N/A	SL-FA + M18 with screw and adhesive fix For rails without channels use SL-SFA
CONCRETE	N/A	N/A	PC-DC1 + F1A + M1B / M2H / VM1 / VMX	PC-DC1 + F1A + M1B / M2H / VM1 / VMX	PC-DC1 + F1A + M2H / VM1	PC-DC1 + F1A + SM1AC	PC-DC1 + F1A + SM2 / SM2H
CONCRETE + TIMBER BATTEN	N/A	N/A	PC-F1A + M1B / M2H / SM2 / SM2H / VM1 / VMX LP-F8 / AF8A + M8A / SM8AS / SMX VL-F3 / F3H + M3 / M3H MC-F5 / F10 + MC-M5	PC-F1A + M1B / M2H / SM2 / SM2H / VM1 / VMX LP-F8 / AF8A + M8A / SM8AS / SMX VL-F3 / F3H + M3 / M3H MC-F5 / F10 + M5	PC-F1A + M2H / SM2 / SM2H LP-F8 / AF8A + M8A / SM8AS / SMX	PC-F1A + SM1AC	PC-F1A + SM2 LP-F8 / AF8A + SM8AS / SMX VL-F3 / F3H / F3FR + M3 / M3H / M3FR MC-F5 / F10 + M5
DRYWALL e.g. Gib Board	N/A	N/A	PC-DC1 + F1A + VM1 / M2H / SM2H LP-DF8 + M8A / SM8AS	PC-DC1 + F1A + VM1 / M2H / SM2H LP-DF8 + M8A / SM8AS	PC-DC1 + F1A + VM1 / M2H LP-DF8 + M8A / SM8AS	PC-DC1 + F1A + SM1AC	PC-DC1 + F1A + SM2 / SM2H LP-DF8 + SM8AS - with epoxy glue
PLYWOOD, MDF	N/A	N/A	PC-F1A / AF1 / SF1 + PC-M1B / M2H / SM2 / SM2H LP-F8 / AF8A + M8A / SM8A / SMX VL-F3 / F3H + M3 / M3H MC-F5 / F10 + M5	PC-F1A / AF1 / SF1 + M1B / M2H / SM2 / SM2H LP-F8 / AF8A + M8A / SM8AS / SMX VL-F3 / F3H + M3 / M3H MC-F5 / F10 + M5	PC-F1A / AF1 / SF1 + M1B / M2H / SM2 / SM2H LP-F8 / AF8A + SM8AS / SMX VL-F3 / F3H + M3 / M3H	PC-F1A / AF1 / SF1 + SM1AC	LP-F8 + SM8AS / SMX - with epoxy glue LP-F8 / AF8A + SM8AS / SMX VL-F3 / F3H / M3FR + M3 / M3H / M3FR MC-F5 / F10 + M5

This Clip Selection Guide should be used as a general guide only. Please email technical@fastmount.com for more detailed advice if required. For overhead panels Fastmount strongly recommends a trial sample be made to prove compatibility of our systems with the panels and substrates in your project.